## MUNICIPAL SEPARATE STORM SEWER SYSTEM (MS4) STORM WATER QUALITY MANAGEMENT FACT SHEET 2




### Compiled By:

City of Cold Spring, Kentucky 5694 East Alexandria Pike Cold Spring, KY 41076 (859) 441-9604

## Stormwater and the Construction Industry



### **Protect Natural Features**



- · Minimize clearing.
- · Minimize the amount of exposed soil.
- Identify and protect areas where existing vegetation, such as trees, will not be disturbed by construction activity.
- · Protect streams, stream buffers, wild woodlands, wetlands, or other sensitive areas from any disturbance or construction activity by fencing or otherwise clearly marking these areas.

### **Construction Phasing**



- Sequence construction activities so that the soil is not exposed for long periods of time.
- · Schedule or limit grading to small areas.
- Install key sediment control practices before site grading
- Schedule site stabilization activities, such as landscaping, to be completed immediately after the land has been graded to its final contour.

### **Vegetative Buffers**





- · Protect and install vegetative buffers along waterbodies to slow and filter stormwater runoff.
- · Maintain buffers by mowing or replanting periodically to ensure their effectiveness.

### Silt Fencing



### Good

- Inspect and maintain silt fences after each rainstorm.
- Make sure the bottom of the silt fence is buried in the ground.
- · Securely attach the material to the stakes.
- Don't place silt fences in the middle of a waterway or use them as
- Make sure stormwater is not flowing around the silt fence.

# Maintain your BMPs!

www.coldspringky.com



### Site Stabilization



Good

· Vegetate, mulch, or otherwise stabilize all exposed areas as soon as land alterations have been completed.

### Construction Entrances




- Remove mud and dirt from the tires of construction vehicles before they enter a paved roadway.
- Properly size entrance BMPs for all anticipated vehicles.
- Make sure that the construction entrance does not become

### **Slopes**



- · Break up long slopes with sediment barriers, or under drain, or divert stormwater away from slopes

### **Dirt Stockpiles**



· Cover or seed all dirt stockpiles.

### **Storm Drain Inlet Protection**



- · Use rock or other appropriate material to cover the storm drain inlet to filter out trash and debris.
- Make sure the rock size is appropriate (usually) 1 to 2 inches in diameter).
- If you use inlet filters, maintain them regularly.

